


Insert Part Number		3523-20.00X2.0DSL	
Insert Thread Form		Metric Fine	
Nominal Thread Size		M20 X 1.50	
Insert Length Q (installed)	D	2.0D	
Insert Length Q (installed)	mm	40.000	
Insert Material		304 Stainless Steel	
Insert Coating/Plating		-	
Military Standard	#	MA3329-222	
National Aerospace Standard	#		
Federal Stock	#	-	
National Stock / NATO	#	-	


Optimum thread performance with Wire Thread Inserts is achieved when the inserts are installed 1/2 to 1 pitch below the surface of the tapped hole. This means that the actual length of an installed insert is equal to dimension Q less 1/2 to 1 pitch. Dimensions S and T allow for tap end clearance of intermediate taps. When using Bottoming and Spiral Flute Taps these dimensions maybe reduced by an amount equal to 2 thread pitches. Any countersink depths must be added to these dimensions.


COMPATIBLE POWERCOIL INSTALLATION	AND REMOVAL TOOLS
TOOL TYPE	Part #
Hand Installation Tool	-
Tang Break Tool	-
Removal Tool	3500-RT3
Machine Installation Tool	-
Mandrel Installation Tool	-
Captive Prewinder Tool	-
Non-Captive Prewinder Tool	3523-20.00HIP
Spring Loaded tang Break Tool	-
Pneumatic Front end assembly (FEA)	-
FEA Mandrel	-
FEA Nozzle	-
Pneumatic Tool	-


powercoil.com.au

PowerCoil is a registered trademark of Bordo International Ptv Ltd Australia













DRILLED HOLE DIMENSIONS INTERMEDIATE/PLUG TAP					
mm	20.50				
	2654-20.50				
inch	13/16				
	2651-13/16				
mm	20.325				
mm	20.561				
mm	46.75				
	inch mm mm				







TAPPED HOLE DIMENSIONS	;		
Tap Size	STI		M20 X 1.50
Tap Size	-		-
B Major Diameter		mm	21.949
C Pitch Diameter MIN		mm	20.974
C Pitch Diameter MAX	5H	mm	21.067
C Pitch Diameter MAX	6H	mm	21.099
T Tapping Depth MIN		mm	45.25
Power Coil Tap Part Number	STI	Taper	3523-20.00T
Power Coil Tap Part Number	STI	Intermediate	3523-20.001
Power Coil Tap Part Number	STI	Bottoming	3523-20.00B
Power Coil Tap Part Number	STI	SpiralPoint	-
Power Coil Tap Part Number	STI	SpiralFlute	-



Number of Free Coils – the number of coils on an un-installed insert counted along the insert length 90° from the tang.

IMPORTANT The success of any drilling and tapping operation is dependant upon many factors -type of material being cut, cutting speed,

is not possible to give specific drill

sizes for each material. Drill sizes

coolant, equipment being used - and it

shown are recommendations only and

PowerCoil would strongly suggest that

independent testing be performed for

specific and critical applications. When using wire thread inserts it is

